



## TECHNICAL BULLETIN: DrySnap -FS1 RE: Use of Furring Strips

Most applications have joists spaced 16" o.c. perpendicular to the main structure going towards the beam. Since DrySnap is installed entirely below the level of the joists, most DrySnap installations are easy to put up & do not require taking additional steps.

On some applications, you may choose to take an optional step of adding furring strips (shown below) to make the installation easier. Typical reasons for taking this step could be: **joists spaced 24" o.c., joists running parallel to the main structure, angled joists, joists running multiple directions, or choosing to rotate the orientation of the system.**

Joist brackets may be installed to the furring strips in either a direct mount (parallel) or a cross mount (perpendicular) fashion. Use of pitch spacers will still be required.



FOR COMPLETE DETAILED INSTRUCTIONS ON INSTALLING DRYSNAP, VISIT:

<http://www.drysnap.com/detail1.html>

